





ASSEMBLY INSTRUCTION

PARTS LIST						
A	BACK BOARD		1	H	PLASTIC BOLT CAP(M8)	 1
B	SIT BOARD		1	I	PLASTIC NUT CAP(M8)	 1
C	BOLT(M6X55)		2	J	NUT(M8)	 1
D	BOLT(M8X50)		1	K	ALLEN WRENCH(M6)	 1
E	METAL WASHER(ø6.5)		2	L	ALLEN WRENCH(M8)	 1
F	METAL WASHER(ø8.5)		2	M	HEX WRENCH	 1
G	PLASTIC BOLT CAP(M6)		2	N	PE WASHER (Φ6.5 PE)	 2



The connection line on the switch button should be in the same direction as the card slot