

21cm

## ARG-SR1037 SNOW ROOF RAKE USER MANUAL



Accessories:



28.5cm

STEP 1: Connect D and E with one shorter hex screw and a nut



STEP 2: Connect A to D and E with two longer hex screw and nuts



STEP 3: Connect B1,B2 and C to A

