

**makute**<sup>®</sup>  
PROFESSIONAL POWER TOOLS

CORDLESS DRILL



**CD007**



Read the booklet of  
instructions carefully  
before using!

**makute**<sup>®</sup>  
PROFESSIONAL POWER TOOLS



**makute**<sup>®</sup>  
PROFESSIONAL POWER TOOLS



## Cordless Drill CD007

Battery voltage	12V / 16V / 20V
No load speed(r / min)	Low speed 0-450 High speed 0-1450
Chuck(mm)	0.8-10

Charging voltage (V) 100-240~

Rechargeable temperature range (°C) 5-40

Producers keep the change specifications without notice of the right

Note: specifications may be varied to different countries

**WARNING:**

Read and understand all instructions. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

**Work Area**

1. Keep your work area clean and well lit. Cluttered benches and dark areas invite accidents.
2. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gasses, or dust. Power tools create sparks which may ignite the dust or fumes.

3. Keep bystanders, children, and visitors away while operating a power tools. Distractions can cause you to lose control.

**Personal Safety**

4. Stay alert, watch what you are doing, and use common sense when operating a power tool. Do not use tool while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tools

may result in serious personal injury. 5. Dress properly. Do not wear loose clothing or jewelry, contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.

6. Avoid accidental starting. Be sure switch is in the locked or off position before inserting battery pack, carrying tools with your finger on the switch or in setting the battery pack into a tool with the switch on invites accidents.

7. Remove adjusting keys or wrenches before turning the tool on. A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.

8. Do not overreach. Keep proper footing and balance at all times. Proper footing and balance enable better control of the tool in unexpected situations.


9. Use safety equipment. Wear eye protection. Dust mask, non-skid safety shoes, hard hat, or hearing protection must be used for appropriate conditions.

**Tool Use and Care**

10. Use clamps or other practical way to secure and support the workplace to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control.

11. 11. Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.

12. 12. Do not use tool if switch does not turn it on or off. A tool that cannot be



controlled with the switch is dangerous and must be repaired.

13. Disconnect battery pack from tool or place the switch in the locked or off position before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.

14. Store idle tools out of reach of children and other untrained persons. Tools are dangerous in the hands of untrained users.

15. When battery pack is not in use, keep it away from other metal objects like : paper clips, coins, keys, nails, screws, or other small metal objects that can make a connection from one terminal to another. Shorting the battery terminals together may cause sparks, burns, or a fire.

16. Maintain tools with care. Keep cutting tools sharp and clean. Properly maintained tools with sharp cutting edge are less likely to bind and are easier to control.

17. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the tools operation. If damaged, have the tool serviced before using. Many accidents are caused by poorly maintained tools.

18. Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool may create a risk for injury when used on another tool.

#### SERVICE

19. Tool service must be performed only by

qualified repair personnel. Service or maintenance performed by unqualified personnel may result in a risk of injury.

20. When servicing a tool, use only identical replacement parts. Follow instructions in the maintenance section of this manual. Use of unauthorized parts or failure to follow maintenance instructions may create a risk of shock injury.

#### SPECIFIC SAFETY RULES

DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to cordless drill safety rules, if you use this tool unsafely or incorrectly, you can suffer serious personal injury.

1. Hold tool by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring. Contact with a "live" wire will also make exposed metal parts of the tool "live" and shock the operator.

2. Be aware that this tool is always in an operating condition, because it does not have to be plugged into an electrical outlet.

3. Always be sure you have a firm footing.

4. Be sure no one is below when using the tool in high locations.

5. Hold the tool firmly.

6. Keep hands away from rotating parts.

7. Do not leave the tool running. Operate the tool only when hand-held.

8. Do not touch the drill bit or the workpiece immediately after operation; they may be extremely hot and could burn your skin.



9. Some material contains chemicals which may be toxic. Take caution to prevent working dust inhalation and skin contact. Follow material supplier safety data.


even if it is severely damaged or is completely worn out. The battery cartridge can explode in a fire.  
9. Be careful not to drop or strike battery.

**IMPORTANT SAFETY**

**INSTRUCTIONS FOR BATTERY**

1. Before using battery cartridge, read all instructions and cautionary markings on (1) battery charger, (2) battery, and (3) products using battery.
2. Do not disassemble battery cartridge.
3. If operating time has become excessively shorter, stop operating immediately. It may result in a risk of overheating, possible burns and even an explosion.
4. If electrolyte gets into your eyes, rinse them out with clean water and seek medical attention right away. It may result in loss of your eyesight.
5. Always cover the battery terminals with the battery cover when the battery cartridge is not used.

6. Do not short the battery cartridge:
  - (1) Do not touch the terminals with any conductive material.
  - (2) Avoid storing battery cartridge in a container with other metal objects such as nails, coins, etc.
  - (3) Do not expose battery cartridge to water or rain. A battery short can cause a large current flow, overheating, possible burns and even a breakdown.
7. Do not store the tool and battery cartridge in locations where the temperature may reach or exceed 50 °C (122°F)
8. Do not incinerate the battery cartridge



**IMPORTANT SAFETY**

**INSTRUCTIONS FOR CHARGER**

1. Before using battery charger, read all instructions and cautionary marking on (1) battery charger, (2) battery. And (3) products using battery.
2. CAUTION: To reduce risk of injury, charge only most rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. Non-rechargeable batteries cannot be charged with this battery charger.
4. Use a power source with the voltage specified on the nameplate of the charger.

5. Do not charge the battery cartridge in presence of flammable liquids or gases.
6. Do not expose charger to rain or snow.
7. Never carry charger by cord or yank it do disconnect from receptacle.
8. After charging or before attempting any maintenance or cleaning, unplug the charger from the power source. Pull by plug rather than cord whenever disconnecting charger.
9. Make sure cord is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress.
10. Do not operate charger with damaged cord or plug-replace them immediately.
11. Do not operate or disassemble charger if it has received a sharp blow, been dropped, or otherwise damaged in any way, take it to a qualified serviceman.

Incorrect use or reassemble may result

- in a risk of electric shock or fire.
- The battery charger is not intended for use by young children or infirm persons without supervision.
  - Young children should be supervised to ensure that they do not play with battery charger.
  - Do not charge battery cartridge when temperature is BELOW 10°C (50°F) or ABOVE 40°C (104°F).
  - Do not attempt to use a step-up transformer, an engine generator or DC power receptacle.

**Tips for maintaining maximum battery charger life**


- Before using battery charger, read all instructions and cautionary markings on (1) battery charger, (2) battery, and (3) products using battery.
- CAUTION:**  
To reduce risk of injury, charge only most rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.

- Non-rechargeable batteries cannot be charged with this battery charger.
- Use a power source with the voltage specified on the nameplate of the charger.
- Do not charge the battery cartridge in presence of flammable liquids or gases.
- Do not expose charger to rain or snow.
- Never carry charger by cord or yank it to disconnect from receptacle.
- After charging or before attempting any maintenance or cleaning, unplug the charger from the power source. Pull by plug rather than cord whenever disconnecting charger.

- Make sure cord is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress.
- Do not operate charger with damaged cord or plug-replace them immediately.
- Do not operate or disassemble charger if it has received a sharp blow, been dropped, or otherwise damaged in any way, take it to a qualified serviceman. Incorrect use or reassemble may result in a risk of electric shock or fire.
- The battery charger is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with battery charger.
- Do not charge battery cartridge when temperature is BELOW 10°C (50°F) or ABOVE 40°C (104°F).
- CAUTION:**  
To reduce risk of injury, charge only most rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.

**Tips for maintaining maximum battery life**

- Charge the battery before completely discharged. Always stop tool operation and charge the battery when you notice less tool power.
- Never recharge a fully charged battery cartridge. Overcharging shorten the battery service life.
- Charge the battery with room temperature 10°C-40°C (50°F-104°F). Let a hot battery cool down before charging it.
- Charge the Nickel Metal Hydride battery when you do not use it for more than six months.



1	Battery
2	Insert shaw
3	Pull out
4	Insert
5	Handle
6	According to
7	Insert
8	Indicator lamp
9	Plc j hds
10	Mark
11	Car light dish
12	mark
13	weak
14	Strong
15	White line
16	Ring
17	Guide set
18	tiffen
19	unscrew
20	Triggf switch
21	Select button
22	R and L mark

- drilling. In fact, this excessive pressure will only serve to damage the tip of your bit, decrease the tool performance and shorten the service life of the tool.
- There is a tremendous force exerted on the tool/bit at the time of hole break through. Hold the tool firmly and exert care when the bit begins to break through the workpiece.
  - A stuck bit can be removed simply by setting the reversing switch to reverse rotation in order to back out. However, the tool may back out abruptly if you do not hold it firmly.
  - Always secure small workpieces in a vise or similar hold-down device.
  - If the tool is operated continuously until the battery cartridge has discharged, allow the tool to rest for 15 minutes before proceeding with a fresh battery.
3. When the battery cartridge is inserted fully, the charging light will change from green to red and charging will begin. The changing light will remain lit steadily during charging.
4. When the charging light changes from red to green, the charging cycle is complete.
5. After charging, unplug the charger from the power source.

**CAUTION:**

- The battery charger is for charging Mosta battery cartridge. Never use it for other purposes or for other manufacturer's batteries.
- When you charge a battery cartridge which is new or has not been used for a long period of time, it may not accept a full charge until after discharging it completely and recharging a couple of times.

**Before using the driver drill, charge the battery as follows.**

1. Plug the battery charger into the proper AC voltage source. The charging light will lighten in green color.
2. Insert the battery cartridge so that the plus and minus terminals on the battery cartridge are on the same sides as their respective markings on the charger.

- If you charge a battery from a just operated tool or a battery which has been exposed to direct sunlight or heat for a long time, the charging light may lighten in green color. If this occurs, wait for a while. Charging will begin after the battery cool.

**FUNCTIONAL DESCRIPTION****CAUTION:**

Always be sure that the tool switched off and the battery cartridge is removed before adjusting or checking function on the tool.

**Installing or removing battery cartridge**

- Always switch off the tool before insertion or removal of the battery cartridge.
- To remove the battery cartridge, withdraw it from the tool while pressing the buttons on both sides of the cartridge.
- To insert the battery cartridge, align the tongue on the battery cartridge with the groove in the housing and slip it into place. Always insert it all the way until it locks in place with a little click. If not, it may accidentally fall out of the tool. Causing injury to you or someone around you.
- Do not use force when inserting the battery cartridge. If the cartridge does not slide in easily, it is not being inserted correctly.

**Switch action****CAUTION:**

- Before inserting the battery cartridge into the tool, always check to see that the switch trigger actuates properly and returns to the "OFF" position when released.

To start the tool, simply pull the switch trigger. Tool speed is increased by increasing pressure on the switch trigger. Release the switch trigger to stop.

**Electric brake**

This tool is equipped with an electric brake. If the tool consistently fails to quickly stop after switch trigger release, have tool serviced at a Mosta service center.

**Reversing switch action**


This tool has a reversing switch to change the direction of rotation. Depress the reversing switch lever from the A side for clockwise rotation or from the B side for counterclockwise rotation.



Battery cartridge



1. Switch trigger



1. Reversing switch lever



1. Lamp



When the reversing switch lever is in the neutral position, the switch trigger cannot be pulled.

**CAUTION:**


- Always check the direction of rotation before operation.
- Use the reversing switch only after the tool comes to a complete stop. Changing the direction of rotation before the tool stops may damage the tool.
- When not operating the tool, always set the reversing switch lever to the neutral

**Lighting up the front lamp****CAUTION:**

- Do not look in the light or see the source of light directly. Pull the switch trigger to light up the lamp. The lamp keeps on lighting while the switch trigger is being pulled.
- Use a dry cloth to wipe the dirt off the lens of lamp. Be careful not to scratch the lens of lamp, or it may lower the illumination.

**Adjusting the fastening torque**

The fastening torque can be adjusted in 19 steps by turning the adjusting ring so that its graduations are aligned with the pointer on the body. The fastening torque is minimum when the number 1 is aligned with the pointer, and maximum when the marking is aligned with the pointer.



1. Graduations
2. Adjusting ring
3. Drill marking
4. Pointer

The clutch will slip at various torque levels when set at the number 1 to 18. The clutch is designed not to slip at the marking.

Before actual operation, drive a trial screw into your material or a piece of duplicate material to determine which torque level is required for a particular application.

**NOTE:**

- The adjusting ring does not lock when the pointer is positioned only halfway between the graduations.
- Do not operate the tool with the adjusting ring set between the number 18 and the marking. The tool may be damaged.

**CAUTION:**

- Always be sure that the tool is switched off the battery cartridge is removed before carrying out any work on the tool.

**Installing or removing driver bit or drill bit**

Hold the ring and turn the sleeve counterclockwise to

open the chuck jaws. Place the bit in the chuck as far as it will go.

Hold the ring firmly and turn the sleeve clockwise to tighten the chuck.

To remove the bit, hold the ring and turn the sleeve counter-clockwise.

**Screw driving operation**


Place the point of the driver bit in the screw head and apply pressure to the tool. Start the tool slowly and then increase the speed gradually. Release the switch trigger as soon as the clutch cut in.

**CAUTION:**

- Make sure that the driver bit is inserted straight in the screw head, or the screw and/or bit may be damaged.

**NOTE:**

- When driving wood screws, predrill pilot holes to make driving easier and to prevent splitting of the workpiece.
- See the chart.

**OPERATION****Drilling operation**

First, turn the adjusting ring, so that the pointer points to the marking. Then proceed as follows.

**Drilling in wood**

When drilling in wood, the best results are obtained with wood drills quipped with a guide screw. The guide screw makes drilling easier by pulling the bit into the workpiece.

**Drilling in metal**

To prevent the bit from slipping when starting a hole, make an indentation with a center-punch and hammer at the point to be drilled.


Place the point of the bit in the indentation an start drilling.

Use a cutting lubricant when drilling metals. The exceptions are iron and brass which should be drilled dry.

**CAUTION:**

- Pressing excessively on the tool will not speed up the

Nominal diameter of wood screw (mm)	Recommend size of pilot hole (mm)
3.1	2.0-2.2
3.5	2.2-2.5
3.8	2.5-2.8
4.5	2.8-3.2
4.8	3.1-3.4
5.1	3.3-3.6
5.5	3.5-3.8
5.8	3.8-4.1
6.0	5.0-5.5

**ASSEMBLY**

1. Sleeve
2. Ring
3. Trigger